



ABSOLUTE PROTECTION

REF.35221

MOUNTING INSTRUCTIONS FOR ENDURO CRD BOOT

- Remove the two original M8 manifold fastening plate nuts (at the point where the muffler is connected to the manifold)
- Remove the lower front motor fastening bolt
- Position the following: the mounting bracket that is supplied with the 42 mm aluminum spacers, screw TH M10 L160mm, and nut M10
- Fix the mounting bracket securely in place
- Mount the boot on the front bracket using screw TH M6 L16mm, and washer M6, all of which are supplied
- Mount the boot on the rear using original nuts

All the parts have been inspected before dispatch. We guarantee only parts that may prove defective before installation. As we do not control the mounting of our products, we cannot be held responsible for personal injuries or technical damage resulting from a wrong assembly carried out by yourself or a third party.